

Stainless Movable Solar Cover Reel

Owner's Manual



SR177-SS



Scan to register your
product warranty

GoPool

Warranty registration

Thank you for choosing GoPool! Register your product today to activate your warranty and get quick, hassle-free support when you need it.



Scan to register your product warranty



WARNING

This equipment must be installed and serviced according to the information found in this manual. Improper installation can create hazards which could result in property damage, serious injury or death. Improper installation will void the warranty.

Table of contents

Warnings & Maintenance.....1

Part number2

Assembly.....3





Structure & part12



Risk of Drowning

- Do not sit or stand on the reel system.
- Do not walk on the pool cover; it is not designed to support the weight of a person.
- Keep children and pets away.
- Remove any water accumulated on the cover.
- Children can drown on top of the cover.
- Completely remove the cover before swimming.
- An improperly secured cover is a hazard.
- Do not allow anyone to swim under the cover.
- Failure to follow these instructions may result in injury or drowning.

Maintenance

- When the cover is not in use, store it away from direct sunlight and heat.
- For long-term storage, rinse and dry the cover and reel system to remove any chemical residue.
- Periodically inspect the hardware and tighten or replace parts as needed.

REQUIRED FOR INSTALLATION			
			
DRILL	SELF-DRILLING SCREWS	STAR BIT	RUBBER Mallet

1  x1	2  x1	3  x2	4  x1	5  x1	
6  x1	7  x1	8  x6	9  x1	10  x6	
11  x1	12  x1	13  x1	14  x2	15 a  b  x20 x10	
16  x12	17  x2	18  x2	19  x1	20  x2	21  x2

01. Inside the largest tube is one of the two smaller tubes. The pre-drilled holes located at one end of the smaller tubes must face the end supports.




02. Insert the tube adapter into the top of the base (see Figure 1).

Then, insert the small tube into the tube adapter.

NOTE -

Make sure the three screw holes located at the end of the tube remain visible.




03. Insert the locking pin.




04. Place the washer into the tube adapter
(see Figure 1).

Insert the M5 × 25 screw and tighten it. Thread the M5
open nut onto the bottom of the screw (see Figure 2).

Install the cap (a rubber mallet may be required).



05. To secure the tube to the adapters, install three ST4.2 × 38 screws on each side and tighten them using a drill.



06. Then, install three ST5.5 × 12 screws into the tube and tighten them using a drill.




07. Install the axle into the T-base.

NOTE -

Make sure the axle extends from both sides.

Then, install the small washer.




08. Slide the wheel onto the axle.



09. Insert the cotter pin through the axle. Bend the ends of the cotter pin outward to secure it in place.

Install the cap (see Figure 1).

Repeat these steps for the second wheel.




10. On the side opposite the wheel handle, insert the second tube adapter into the top of the base.

Insert a small tube into the tube adapter.

NOTE -

Make sure the three screw holes located at the end of the tube remain visible.


Insert the locking pin. (see Figure 2)



11. To secure the tube to the adapters, install three ST4.2 × 38 screws on each side and tighten them using a drill.



12. Then, install three ST5.5 × 12 screws into the tube and tighten them using a drill.



13. Slide the wheel handle onto the top of the base. Align the hole in the wheel handle with the pre-drilled hole in the tube adapter axle. If necessary, use a rubber mallet.



14. Insert the M5 × 65 screw, then secure it with the M5 closed nut.



15. Adjust the length of the tubes to fit the width of your pool.

Slide the steel mounting bracket into the groove until it is in position. **(see Figure 1)**

Insert a self-drilling screw into the small groove of the tube, next to the bracket, then tighten it using a drill. **(see Figure 2)**

Repeat the previous steps to install the second mounting bracket on the other side of the reel.

Figure 1





Figure 2






16. The straps must be attached to the tubes with self-drilling screws, evenly spaced along the length and centered with the pool.




17. Using scissors or a screwdriver, carefully make a hole in the solar cover. (see Figure 1)

The straps must be attached to the solar cover using the nylon plates, nylon bolts, and nylon nuts. (see Figure 2-3-4)



Structure & parts



Ref. No.	Part No.	Description	Quantity
1	649417711080	Cover for axle	1
2	65244009000	Gasket (ø36*ø20.5*2)	1
3	649417702080	Fix clip	2
4	649417772000	Stainless steel support assembly	1
5	649417779000	Screw M5*25 and Nut M5	1
6	649417773000	Plastic adaptor with Aluminum axle	1
7	94193	Aluminum tube sets(Dia.90mm)	1
8	65212015000	Screw ST5.5*12	6
9	649417774000	Plastic Adapter with Aluminum Axle (Ø 90 mm, Wheel Side)	1
10	65212024107	Screw ST4.2*38	6
11	649417772000	Stainless Steel Bracket (Wheel Side)	1
12	64941778000	Screw M5*65 and Nut M5	1
13	649417777000	Wheel Handle	1
14	64941778000	Steel Mounting Bracket	2
15	649413373002	Solar Cover Strap Kit	1
16	65211012000	Screw ST6.5*25	12
17	649417710080	Wheel Cover	2
18	65244008000	Gasket (ø22*ø13*1)	2
19	65318007000	Wheel Axle	1
20	65243002000	Cotter Pins	2
21	649417725001	Plastic Wheel	2

Use only GoPool genuine replacement parts.

GoPool

Need parts or accessories ?
GoPool.com